

photomultiplier amplifier-discriminator

AD7 data sheet

1 description

The AD7 amplifier-discriminator is a printed circuit mounting module intended for use in fast photon counting or pulse counting systems. A TTL output pulse is produced for each input pulse from the photomultiplier tube that exceeds the adjustable threshold level.

The AD7 is housed in a tin plated steel enclosure providing excellent electrical shielding. Power and signal connections are via six insulated feed-through pins, facilitating direct mounting onto a printed circuit board.

2 applications

- can be used for fast photon counting or pulse counting systems
- ideal for use in battery powered, portable instruments

3 features

- wide dynamic range
- adjustable threshold
- low power consumption
- fully screened enclosure
- direct mounting to pcb
- the threshold level is factory set to -2 mV but can be adjusted between -2 mV and -5 mV by use of a multiturn potentiometer accessible through the top of the unit

4 characteristics

input impedance	50 Ω
input threshold	-2 mV to -5 mV
input protection	limiting diodes
output pulse	TTL high level
output pulse amplitude (unterminated)	5 V
output pulse rise time	2 ns
output pulse fall time	2 ns
output impedance	50 Ω
pulse pair resolution	24 ns
power input at 10^6 s^{-1} count rate	+5 V, 10 mA
supply voltage	+4.75 V to +5.25 V
temperature: operating	+5 °C to +55 °C



Examples of the ET Enterprises range of Amplifier Discriminators

5 dynamic range


Maximum dynamic range can be realised by applying count rate correction to compensate for departure from linearity at high count rates due to pulse pile up:

$$\text{True count rate } N = \frac{n}{1 - nT}$$




where n is the measured count rate (s^{-1}) and T is the count rate correction factor, in this case $2.4 \times 10^{-8} \text{ s}$.

Using count rate correction, deviation from count rate linearity is typically within $\pm 5\%$ at $2 \times 10^7 \text{ s}^{-1}$. Above this rate, the correction becomes less reliable.

The AD7 has high input sensitivity requiring careful attention to pcb layout and system cabling.



6 outline drawings (mm)



access to threshold adjustment

7 connections

1	signal input
2	signal input ground
3	+5 V
4	0 V
5	signal output
6	signal output ground

The enclosure is internally connected to 0 V.

8 ordering information

The AD7 is also available with a prescaler which can be factory set to divide the output count rate by any integer from 2 to 16. This facility is intended for applications where the count rate performance of associated electronics may be too slow to enable the full dynamic range of the AD7 to be realised.

9 warning

Do not operate beyond the maximum ratings, or reverse the input voltage; this may result in loss of performance or permanent damage.

ET Enterprises Limited
45, Riverside Way
Uxbridge, UB8 2YF
United Kingdom
tel: +44 (0) 1895 200880
fax: +44 (0) 1895 270873
e-mail: sales@et-enterprises.com
www.et-enterprises.com

ADIT Electron Tubes
300 Crane Street
Sweetwater, TX 79556, USA
tel: (325) 235 1418
toll free: (800) 399 4557
fax: (325) 235 2872
e-mail: sales@electrontubes.com
www.electrontubes.com

an ISO 9001 registered company

The company reserves the right to modify these designs and specifications without notice. Developmental devices are intended for evaluation and no obligation is assumed for future manufacture. While every effort is made to ensure accuracy of published information the company cannot be held responsible for errors or consequences arising therefrom.

ET Enterprises
electron tubes

© ET Enterprises Ltd, 2011
DS_AD7 Issue 4 (27/09/11)